



Installation Instructions

Em-Pad Adjustable Paving Support

1. Measure the total area to be paved to determine the number of Em-Pad paving support pads required.
2. Use sight or laser lines to mark the intersections of the corners of each paver to be laid.
3. Position Em-Pad Adjustable Paving Support without tabs where edges and corners are to be supported. If necessary, saw along marked score lines on the bottom of the units so that units may be positioned along wall edges or in corners.
4. Commence paving by positioning the first paver in a corner and subsequent pavers along a wall edge.
5. Place the Whitesales Em-Pad Adjustable Paving Support starting from the base and simply adjust the column and collar either up or down to ensure each paver is level according to the height required.
6. Position Top Section and tabs and adjust the inclination to compensate the slab up to +/-5% slope.