


DOWNPIPE - PLAIN ENDED

CODE	LENGTH	A
BR500	2m	65
BR501	2.5m	65
BR503	4m	65
BR504	5.5m	65





DOWNPIPE CONNECTOR

CODE	A	B
BR506	49	24





DOWNPIPE BRACKET

CODE	A	B	C
BR507	63	90	112





DOWNPIPE BEND - 92 1/2°

CODE	A	B	C
BR508	33	34	38





DOWNPIPE BEND TOP & BOTTOM OFFSET - 112 1/2°

CODE	A	B	C
BR509	22	41	38





DOWNPIPE SHOE - 112 1/2°

CODE	A	B	C
BR516	50	102	38





DOWNPIPE BRANCH - 112¹/₂°

CODE	A	B	C
BR518	52	91	38





ACCESS PIPE

CODE	A	B	C
BR510	45	133	78



DOWNPIPE RAINWATER HEAD

CODE	A	B	OVERALL WIDTH
BR511	176	136	274




SQUARE TO ROUND ADAPTOR

CODE	A	B
BR517	46	3




UNIVERSAL ADAPTOR (SOCKET)

CODE	A	B	C
B4901	148	57	31



UNIVERSAL ADAPTOR (PIPE)

CODE	A	B	C
B4801	148	72	31



NB: Use Rainwater Adaptor BR517 to connect to Square Pipe

DRAIN CONNECTOR

CODE	A	B	C
BR520	139	55	65

